

## **Diagnostics and Repair**

### **How can you make sure the ROV is water tight after you open it in the field?**

VideoRay offers a leak detector, which can be used to check for leaks. Using the leak detector, pressurize the main housing to no more than 10 psi. Put the ROV under water and make sure there is not a steady stream of bubbles.

Unique solution ID: #1023

Author: Tom Glebas

Last update: 2012-07-21 00:44