

Turner Designs

Does the C3 need to be permanently installed on the VideoRay ROV?

The C3 can be installed (or removed) easily in the field by removing and then reinstalling 4 screws, and attaching (or removing) the interface cable.

Unique solution ID: #1018

Author: Tom Glebas

Last update: 2012-07-21 00:37