

Turner Designs

The C3 can only transmit RS-232 up to 10 meters without using boosters. Are these boosters necessary?

Boosters are not necessary. The interface cable between the C3 and VideoRay that is included as part of the C3 Integration Kit includes a VideoRay PAM (Protocol Adapter Multiplexer). The PAM converts the RS-232 from the C3 to RS-485, VideoRay's standard data protocol, which can transmit to the maximum VideoRay deployment distance.

Unique solution ID: #1056

Author: Tom Glebas

Last update: 2012-11-27 21:18