

ROV Systems

What is the pin-out for the tether and 8 pin tether connectors on the control panel and the ROV?

Pro 4

Pin Function

- 1 Video-
- 2 Video+
- 3 74 VDC
- 4 AUX+
- 5 Ground
- 6 AUX-
- 7 RS-485 -/A
- 8 RS-485 +/B

Scout, Explorer, Pro 3, Pro 3 GTO, Deep Blue

Pin Function

- 1 Video-
- 2 Video+
- 3 48 VDC
- 4 AUX+
- 5 Ground
- 6 AUX-
- 7 CAN+
- 8 CAN-

Scout and Explorer models do not use the AUX wires.

Unique solution ID: #1090

Author: Tom Glebas

Last update: 2012-12-18 22:03