

ROV Accessories

How wide do the jaws of the manipulator open?

The jaws open 5 cm (2 inches).

Unique solution ID: #1042

Author: Tom Glebas

Last update: 2012-11-27 19:07