

ROV Accessories

What are the proper switch settings for the dip switch in the Sea Level rs-485 to USB adapter?

All switches should be set to ON for most applications.

Unique solution ID: #1066

Author: Tom Glebas

Last update: 2012-11-27 21:40